



Bill Of Materials:

Handrail (plus inserts) - 2 x 1828mm

Spindle - 15 x 952mm

Spindle props - 2 x 100mm



Assembly Method:

- 1) Fix 2 end spindles to posts using at least 4 screw points at a base height of 124mm above deck
- 2) Sub-assemble spindles onto insert strips using spacing guide shown
- 3) Slide sub-assembly over post mounted spindles
- 4) Screw insert to the 2 post mounted spindles
- 5) Fit handrails over complete assembly

NB: SPINDLE IS SLIGHTLY WIDER ONE WAY, TRY TO USE THE THICKER SIDE TO GIVE A GOOD INTERFERENCE FIT WITH THE ROUTED HANDRAIL CHANNEL

Title: Spindle / Handrail Assembly	
Material: Ecodek wood/plastic composite	
Date: 07/07/2006 All Dimms in Millimetres	